



SEKONIC
AUTO-LUMI
model L-158
INSTRUCTIONS



Instructions for use

Part Designations



Sensor (1)

Pointer (2)

Guide mark (3)

Movie scale (4)

Shutter speed scale (5)

f/number scale (6)

DIN scale (7)

ASA scale (8)

ASA set knob (9)

EV scale (10)

Dial ring (11)

Specifications

Measurement system:

Reflected light system

Measurement range:

EV7 to 17 (ASA 100)

Angle of incoming light:

65°

Scales: * ASA (DIN) . . . 6 (9) to 12000 (42)

* f/number . . . 1 to 64

* Shutter speed (T) . . . 8 to 1/2000 sec.

* EV . . . -2 to 19

Dimensions : 81 x 52 x 24.5mm

Weight : 50g

The Auto-Lumi is a very handy carry-around exposure meter. It allows the exposure to be measured very easily thanks to its pointer-tracking system which is based on the guide mark.

Film speed setting

Set the film speed setting which you intend to use. How to set the film speed

For, the correct setting on the ASA scale (8), rotate the ASA set knob (9) and align the white mark on the black dial with the red scale unit in the ASA window.

Reading out the exposure

When the sensor (1) is pointed in the direction of the subject, the pointer (2) deflects in accordance with the brightness of the subject. To read out the exposure, rotate the dial ring (11) and set so that the pointer (2) is aligned with the center of the guide mark. The correct exposure will be the combination of the shutter speed scale (5) unit on the dial and the f/number scale (6) unit.

In the illustrated example, f/5.6 will be the correct exposure at 1/125 sec. and f/8 at 1/60 sec.



